
"Horizontal Airflow" Does Not Blow Cool Air Directly at the Occupants in the Room



Outside air conditions: 35°C, 40% humidity

Operation contents: Cooling

Set temperature (Min. set temp) 18°C, Air flow Hi


Vertical flap: Upward Horizontal flap: Center

With "Horizontal Airflow" design, cold air no longer blows directly at occupants. By evenly distributing the airflow across the room, it brings much-needed comfort for users.

Easy Maintenance

Simplification of drain pan cleaning improves maintenance-ability.

Air Conditioner Filter Features



Optional Parts —

Wired Remote Control: UTY-RNNYM Simple Remote Control: UTY-RSNYM External Connect Kit: UTY-XWZX